














PART LIST	PICTURE	QTY	DESCRIPTION	PART LIST	PICTURE	QTY	DESCRIPTION
A		4	ROOF WITH HOOK IN CORNER	B		2	ROOF FOR MIDDLE (WITHOUT HOOK)
C		2	DÉCOR PANEL	D		4	CONNECT SIDE PANEL
E		2	STAND-LEFT	F		2	STAND-RIGHT
G		2	STAND-MIDDLE	H		4	BRACKET INSIDE
I		8	nuts	J		1	tool




Step1: Fix two pieces roof with hook in corner (A) to form a whole piece. Fix the other two pieces A too.




Step2: Fix two pieces décor panel (C) to the whole parts from step 1.




Step3: Fix two pieces roof for middle (B) together to form a whole part.



Step4: Put the part from step 3 in the middle and the parts from step 1 on the left and right, fasten them to form a roof.



Step5: Fix middle stands (G) to middle roofs (B), and left stand (E) and right stand (F) to left and right roof.



Step6: Fix 4 pieces connect side panel (D) to the stands, and fix 4 pieces bracket inside (H) to left stands (E) and right stands (F).