



CAUTION:

1. For indoor use only.
2. Keep out of the reach of children and animals.
3. Use 240V 50 Hz, Max 40W, E27 Bulbs Only.
4. Do not use in the bathroom or damp places.
5. Place the lamp on a flat surface and ensure there are no flammable materials around it.
6. Before cleaning the lamp, ensure it is switched off.
7. Before replacing the bulb, ensure the plug has been out from socket and the lamp has cooled down.
8. Do not pull the plug out from the socket with wet hands.
9. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
10. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.